


Measurements

SALZBURG L BASIC/ SALZBURG L BASIC + 1

 Nordpeis

FIG 1

SALZBURG L BASIC = MM




Measurements

SALZBURG L BASIC/ SALZBURG L BASIC + 1



FIG 2

SALZBURG L BASIC + 1 EXTENSION = MM




Measurements

SALZBURG L BASIC/ SALZBURG L BASIC + 1



FIG 3

SALZBURG L BASIC + EXTENSION BASE = MM



Measurements

SALZBURG L BASIC/ SALZBURG L BASIC + 1

FIG 4

SALZBURG L BASIC/ SALZBURG L BASIC + EXTENSION BASE
SALZBURG L BASIC + 1 EXTENSION = AIR

